

# 10 x 10 Cabana

## Parts:

12	6'6" Galvanized Pipe
4	2'9" Galvanized Pipe
4	4 Way Corner Galvanized Fitting
1	2 Piece Galvanized Fitting
4	6" Foot Anchor
4	4 Ball Bungees
1	UV Rated Cover

## Instructions:

1. Arrange all pipe and fittings on the ground.
2. Insert one swedged end pipe into one long pipe. This extended pipe will be inserted into each corner fitting to form the length of the sides. Insert long pipe to form roof supports.
3. To form peak insert two of the long pipe into both ends of half of the two piece center fitting. Repeat for the other cross section. Push the 2'9" pipe into the fitting until it stops.
4. Place cover over frame with velcro strips facing down. Do not fasten velcro straps at this time.
5. Lift one side of frame and insert 2 long pipes for the legs and repeat on the other side.
6. Slide one anchor foot on each leg and tighten.
7. Pull cover down on all four sides of the frame.
8. Take ball bungees and insert through grommet holes. Keep the two sides of the bungee together as you pull the strap down and around the thumb screw in the anchor foot. Pull it back up to the hook that is attached to the inside of the cover. Open the bungee and slip over hook.
9. Attach the velcro straps.

Note\*\*\*When used as a hammock stand extra support is needed.

