



■ **9315 Impact Universal Drip Tray Mounting Instructions**

Tape Mount Option

1. Line up drip tray with the soap dispenser.
2. Peel film from mounting tape on back of dispenser and adhere to clean, dry, smooth surface directly beneath the soap dispenser.

Screw Mount Option

1. Use appropriate anchors/fasteners for wall substrate.
2. Remove screw covers and use the holes on the drip tray to mark the hole location on the wall.
3. Drill hole in wall. Attach drip tray to wall using appropriate hardware.
4. Replace screw covers on the drip tray.

*Prior to mounting the drip tray, ensure that there is enough clearance for the dispenser cover to open properly.

**For electronic hands-free dispensers consult dispenser instructions to ensure location of the drip tray does not interfere with sensors.

IMPACT PRODUCTS, LLC

2840 Centennial Road • Toledo, OH 43617
419.841.2891 • 800.333.1541 • impact-products.com



A Supply Source Company
supplysourceglobal.com