

MICROFIBER TOWEL FORMULA



1. Load washer to 60%-75% of capacity.
2. Avoid washing with cloths containing cotton.
3. Keep colors and whites separate.
4. Pre-flushes remove much water soluble and loose soils
5. **NEVER USE CHLORINE BLEACH**
6. **NEVER EXPOSE TO FABRIC SOFTENER**
7. Temps should not exceed 180 degrees

Regular Soil				
Operation	Time	Temp	Water Level	EcoLab/CWT
Pre flush (optional)	2 min	Hot High		
Suds	10 min	Hot Low	Turbo	Chargell/6 oz Turbo Lifter/1 oz
Rinse	2 min	Hot High		
Rinse	2 min	Split High		
Rinse	2 min	Split High		
Rinse	2 min	Split High		
Extract	4 min			
Heavy Soil				
Operation	Time	Temp	Water Level	EcoLab/CWT
Pre flush (optional)	2 min	Hot	High	(use additional pre flush if needed)
Suds	15 min	Hot	Low	Turbo Chargell/8 oz Turbo Lifter/1.5 oz
Oxy bleach	10 min	Hot	Low	Turbo Guard/6 oz
Rinse	2 min	Hot	High	
Rinse	2 min	Split	High	
Rinse	2 min	Split	High	
Rinse	2 min	Split	High	
Extract	4 min			

MICROFIBER WET MOP FORMULA



1. Suds cycle @ 160°-180 No Carryover	6 minutes
2. Drain	1 minute
3. Hot rinse @ 160°-180	2 minutes
4. Drain	1 minute
5. Warm rinse @ 120°	2 minutes
6. Drain	1 minute
7. Cold rinse	2 minutes
8. Drain	1 minute
9. Extract	6 minutes
10. Fill time	<u>4 minutes</u>
Total Time	20 minutes

NOTES: DO NOT use fabric softener

DO NOT use chlorine bleach

MICROFIBER DRYING FORMULA



Warm heat @ less than 120°	12 minutes
Cool Down	<u>2 minutes</u>
Total Drying Time	14 minutes