



Touchless Trashcan[®] TX

USER MANUAL



Quick Start Guide

1. Make sure the power is turned off (The side with red dot is off position)
2. Slide the battery cover down to open the battery compartment.
3. Install 4 AA alkaline batteries with the correct +/- directions
4. Close the battery cover before turn on the power

DO NOT FORCE THE LID TO CLOSE. Let it close automatically.

Cleaning:

Use a soft damp cloth to wipe clean the sensor eye often. Do not use chemical detergence or steel wool to clean the trash can.



Remove top unit to access the inner bucket



Remove inner bucket for easy cleaning



Manual override open/close buttons next to the sensor eye

Automatic Opening:

Sensor beam range is about 5 inches straight from the sensor eye. Put object in the sensor range to break the beam. The lid will open automatically. The lid will remain open for as long as an object is within the sensor range.

Automatic Closing:

4 seconds after the object remove from the sensor range, the lid will close automatically. **DO NOT FORCE THE LID TO CLOSE.** It will damage the lid mechanism. Always let it close automatically.

Manual Override Buttons:

Push the Open button to keep the lid open for extended jobs. To resume automatic functions, push the Close button.

IMPORTANT: If your Touchless Trashcan does not work or you have additional questions, please contact iTouchless Customer Service at 1-800-660-7978 Monday to Friday from 9:30am to 5:00pm PST. Or contact us through our website www.TouchlessTrashcan.com

DO NOT RETURN THIS ITEM TO THE STORE OR RETAILER WHERE YOU PURCHASE IT.

THREE (1) YEAR LIMITED WARRANTY

Touchless Trashcan is distributed by iTouchless Housewares & Products, Inc. (iTouchless) with the highest quality components and most advanced technology available. The Trash Can is warranted to be free from defects in material and workmanship, given normal use and care, for 365 days from the date of the original purchase with proof of purchase within the United States or Canada. iTouchless will only honor warranty requests from orders placed with our authorized dealers. Items sold as used, floor sample or refurbished are sold solely under the terms and conditions of the selling party, iTouchless will not warrant such purchase. We will repair or replace a working condition Trash Can thereof which fails as the result of such a defect during the warranty period.

This warranty is the customers' exclusive remedy for product defect and does not apply to:

- User modification
- Attachments to product by user that causes damage
- Any product, on which the seals and/or serial numbers have been broken, removed, tampered with, defaced or altered in any manner
- Damage caused by abuse, misuse, accident, water or theft

Except as stated above, iTouchless makes no express or implied warranties as to any product, in particular, makes no warranty of merchantability or of fitness for any particular purpose. iTouchless shall not be liable for consequential or incidental damages arising from any product defect. Our Liability is limited to the replacement of any defective product. iTouchless expressly disclaims all warranties not satisfied in this limited warranty. Any implied warranties that may be imposed by law are limited to the terms of this limited warranty. The Plastic Bucket and Battery Cover are not covered by this warranty.

If Trash Can should fail during the warranty period, contact us through <http://www.TouchlessTrashcan.com> to request a Repair# before returning to us. We WILL NOT ACCEPT package that without the Repair#. Remember to return package FREIGHT PREPAID by an insured carrier such as UPS and include a check of \$9.95 for return postage. Extra \$10.00 should be added to return postage when requesting repaired item to be shipped to Canada. We will not pay for any return postage fee.

Return Address:

**iTouchless Housewares & Products Inc.
3151 Diablo Avenue, Hayward, CA 94545, USA**

Subject to the above conditions, we will repair or ship you a new Trash Can within 30 working days after receipt.

This warranty gives you specific legal rights, and you may also have other rights that vary from state to state and province to province. For more information, please visit our website at <http://www.TouchlessTrashcan.com>

Thank you for purchasing the Touchless Trashcan' !