

Instructions for Installing Coin Mechanisms (Plastic)

impact[®]
Everything.

Impact Products
2840 Centennial Road
Toledo, Ohio 43617-1831
www.impactproducts.com

IMPORTANT

When replacing the metal coin mechanism, use Allen Wrench to remove handle and follow the instruction below to install new mechanism.

Tools Needed: Phillips head screwdriver (not provided).

1. If the handle is affixed to the coin mechanism, use the screwdriver to remove the screw from the back of the mechanism and remove the handle.

2. With vendor door open, insert top of coin mechanism UNDER THE MECHANISM RETAINER until the mechanism locks into place.

The mechanism plate collar should be pushed through the smallest hole on the door.

The mechanism must lay FLAT against the back of the door.

3. Reattach the handle using the screwdriver and screw from step 1.

The cam and handle are made so the handle will only fit onto the cam one way. If the handle will not slide onto the cam, the cam is probably out of position. Twist the cam until it clicks into position and will no longer turn, then install the handle. When properly installed, the handle points to approximately the seven o'clock position. Vendor is now ready to be loaded with product.

If installing two or three mechanisms, repeat above procedures.