



GENERAL CARPET CLEANERS

LB #21 ANSWER™ MULTI-USE CARPET CLEANER	RINSE AWAY™	SUPER CARPET & UPHOLSTERY SHAMPOO	WATER EXTRACTION CARPET CLEANER	CSQ-2000	X-TRAX®
FOUR FORMULAS IN ONE; PRESPRAY, SPIN CLEAN, EXTRACTION, SPOTTER	DETERGENT BUILD-UP REMOVER, CARPET CONDITIONER	DRY FOAM ROTARY SHAMPOO	HIGH pH EXTRACTION CLEANER	SANITIZING SPIN BONNET & EXTRACTION CLEANER	NEUTRAL pH EXTRACTION CLEANER
This unique formulation meets most every carpet cleaning need that one may encounter and provides safe/carefree maintenance of carpet. As a spotter it removes tough soils such as food, pet stains and even dirty motor oil, as a prespray, spin clean or extraction cleaner it brings these tough soils away from the carpet fibers without leaving a residue that attracts soils.	Works to remove detergent build-up, alkaline residue and browning stains on carpet. This formulation is an important part of any carpet maintenance system. Using RINSE AWAY as an extraction cleaner removes this residue and restores the original condition of the carpet.	Provides a very dry foam that works with common rotary machines and the appropriate brush or with other dry foam commercial equipment. The formulation cleans deep into the pile and captures the soil, while surrounding each fiber with a soil resistant coating. The captured soil lays on the surface of the pile and is vacuumed away.	Formulated for hot water extraction systems and provides an aggressive combination of ingredients for cleaning carpets that are loaded with tough soils. Designed for use where the soil load is the carpet's worse enemy.	Sanitizes and deodorizes carpets using hot water extraction or bonnet cleaning methods. Contains twin chain quaternary ammonium chloride compounds that reduce the growth of odor-causing bacteria. Optimized for use on washable synthetic carpets, but not recommended for wool carpets or new stain resistant carpets.	Neutral pH extraction cleaner that is specifically designed for "new generation" stain resistant carpets. Removes deeply embedded soils, low foaming and low odor.
Use for daily, interim and restorative maintenance of carpets at schools, restaurants, nursing homes, offices, department stores, hospitals and hotels.	Use for restorative maintenance of carpets in schools, restaurants, nursing homes, offices, department stores, hospitals and hotels. Very low odor.	Ideal for interim maintenance of carpets and restorative maintenance of upholstery in schools, offices, department stores, automobiles, restaurants and hotels.	For salvage and restorative cleaning of carpets in schools, industrial offices, department stores, hotels and restaurants.	Ideal for use on carpets with water damage, restaurant eating areas, carpeted rest rooms and carpets with inherent moisture problems. For use in restaurants, schools, nursing homes, hospitals, offices, department stores and hotels.	Excellent for maintaining the carpet's appearance in restaurants, schools, universities, hospitals, churches, homes, convention centers, offices, hospitals and department stores.
Dilution: 1:128 ratio, 1 ounce per gallon of water for extraction or spin bonnet 1:64 ratio, 2 ounces per gallon of cool water for prespray 1:32 ratio, 4 ounces per gallon of cool water for spotting	Dilution: 1:128 ratio, 1 ounce per gallon of hot water for extraction 1:32 ratio, 4 ounces per gallon of water for spotting	Dilution: For normal use: 1:50 ratio, 2.5 ounces per gallon of cool water	Dilution: For normal use: 1:128 ratio, 1 ounce per gallon of hot water	Dilution: 1:64 ratio, 2 ounces per gallon of hot water for extraction 1:32 ratio, 4 ounces per gallon of cool water for spotting	Dilution: 1:128 ratio, 1 ounce per gallon of hot water for extraction 1:8 ratio, 16 ounces per gallon of cool water for prespray
Approved: Wool's of New Zealand	Approved: Wool's of New Zealand			EPA Reg. No. 6836-108-1124	
Prod. Code: F3804	Prod. Code: F3798	Prod. Code: F5380	Prod. Code: F5340	Prod. Code: F2440	Prod. Code: F5345
Size: 4/1gl, 1/5pl, 55/dr	Size: 4/1gl	Size: 4/1gl, 1/5pl	Size: 4/1gl, 1/5pl, 1/55dr	Size: 4/1gl	Size: 4/1gl
Fragrance: Apple	Fragrance: Lemon	Fragrance: Banana	Fragrance: Floral	Fragrance: Quat	Fragrance: Lime
Color: Light Straw	Color: Clear Yellow	Color: Clear Colorless	Color: Light Blue	Color: Clear Colorless	Color: Clear to Pale Yellow
pH: 8.0 ± 0.5	pH: 1.5 ± 0.3	pH: 9.5 ± 0.5	pH: 13.05 ± 0.35	pH: 12.9 ± 0.4	pH: 8.45 ± 0.35

FRANKLIN CLEANING TECHNOLOGY
Great Bend, KS 67530
Tel: (800) 848-4901, Fax: (316) 792-3146



NOTICE: Consult the appropriate Franklin Product Label or Technical Data Sheet for use directions and additional information.