



Creating Integrated Solutions
Since 1888

333 Hollenbeck Street Rochester, NY 14621 USA
585-336-2200 Fax: 585-336-2357
www.rochestermidland.com

ENVIRONMENTAL & SAFETY BENEFITS

- Non Toxic (aquatic & human)
- Non-Flammable
- Phosphate Free
- Biodegradable*
- Contains No Hazardous Ingredients**
 - No Petroleum Distillates
 - No Glycol Ethers
 - No Alkalies
- Non-Corrosive
- VOC Compliant
- Made Using Renewable Resources
- NPE-Free
- Fragrance Free (no added perfumes)

DILUTION RATIO

1:80, 1 1/2 oz. per gallon. Snap container makes 40 gallons or 160 quart bottles.

Dilute with water from the cold tap.

DIRECTIONS FOR USE

EC Tough Job Cleaner (Snap Concentrate) may be used as a "Spray and Wipe" cleaner, and for damp mopping, automatic scrubbing, hand scrubbing or through high-pressure washers and steam cleaners. **EC Tough Job Cleaner (Snap Concentrate)** may also be used in cold tank soaking applications and will not discolor or harm aluminum or other soft metals. When used for carpet spot remover or pre-spray, test carpet for color-fastness before using. Allow 5 to 10 minutes before beginning the shampooing or spot removal process.

Meets USDA standard rating C1
Letter of Guaranty available upon request.

E N V I R O C A R E ®

Tough Job (Snap Concentrate)

PRODUCT PERFORMANCE CHARACTERISTICS

A heavy-duty liquid cleaner that's strong enough for the most difficult cleaning tasks. **ENVIRO CARE Tough Job Cleaner (Snap Concentrate)** will remove carbon and greasy residues from walls, floors, machinery - any washable surface.

ENVIRO CARE Tough Job Cleaner (Snap Concentrate) also excels at removing forklift tire marks and is perfect for fire and smoke damage clean up. **ENVIRO CARE Tough Job Cleaner (Snap Concentrate)** may be used as a "spray and wipe" cleaner, and for damp mopping, automatic scrubbing, hand cleaning or through high-pressure washers and steam cleaners. **ENVIRO CARE Tough Job Cleaner (Snap Concentrate)** may be used in cold tank soaking applications and will not discolor or harm aluminum. **ENVIRO CARE TOUGH JOB CLEANER (SNAP CONCENTRATE)** is VERSATILE! It performs at it's peak as a carpet or upholstery pre-spotter, stain remover and traffic lane cleaner. (See label for complete directions).

TYPICAL PROPERTIES

Non-Volatile Material	14.0%
pH	9.75
Specific Gravity	0.985
Weight	8.2 lbs/gallon
Foam Height (2%)	5 cm ³
Foam Height (10%)	12 cm ³
Color	Orange
Odor	Mild orange
Clarity	Clear
Sediment	None
VOC's (% by weight)	2.60%

HEALTH AND HAZARD RATINGS

CATEGORY	NFPA	HMIS
Health	0	0
Fire	0	0
Reactivity	0	0
Protective Equipment	None	None

* As defined in 40CFR796.3200 EPA/TSCA

** As defined in OSHA 29CFR 1910.1200

All data statements and information presented herein are believed to be accurate and reliable but are not to be taken as a guarantee, express warranty or implied warranty or merchantability or fitness for a particular purpose, or representation, express or implied, for which seller assumes legal responsibility, and they are offered solely for your consideration, investigation and verification. Statements or suggestions concerning possible use of this product are made without representation or warranty that any such use is free of patent infringement and are not recommendations to infringe on any patent. Printed in USA. Copyright © 2001 Rochester Midland Corporation.
Form # 4253



Printed on recycled paper