



F0624

Multi-Surface Cleaner/Degreaser

READY TO USE**PRODUCT DESCRIPTION:**

Multi-Surface Cleaner/Degreaser uses advanced no-drip technology to eliminate drips and runs when applied to surfaces. Spray gel clings on contact and easily glides over any surface with ease and minimum effort. Microcapsules burst on contact and provide full strength cleaning power. Each microcapsule contains natural concentrated orange oil to clean surfaces. Works on most hard surfaces including sealed wood, marble and tile. Not for use on unsealed wood surfaces.

FEATURES:**Advanced Technology:**

Unique gel formulation results in less product used, which helps lower cleaning costs.

Easy To Use:

Easy-to-grip trigger-style bottle . Simply attached sprayer and go to work.

Labor Saving:

No-drip formula stays where you spray it, which makes the cleaning process more labor efficient.

Safe:

Multi-Surface Cleaner/Degreaser is not atomized into ambient air like traditional cleaners. This unique product helps improve indoor air quality (IAQ) and reduce respiratory exposure to cleaning products.

PRODUCT SPECIFICATIONS:

pH (concentrate)	8.0 ± 1.0
Appearance	Clear Orange Liquid
Fragrance	Orange
Freezing Point	About 32°F
Solubility in Water	Complete
Flash Point	142°F

INGREDIENTS:

Water	7732-18-5
Isopropyl Alcohol	67-63-0
Propylene glycol n-propyl ether	1569-01-3
Ethoxylated nonylphenol surfactant	9016-45-9
Ammonia	7664-41-7

ECOLOGICAL INFORMATION

- Biodegradable Surfactants
- Contains no Phosphorus

DILUTIONS	HEALTH	FLAMMABILITY	REACTIVITY
CONCENTRATE CONCENTRACIÓN	NFPA 2 HMIS	NFPA 1 HMIS	NFPA 0 HMIS
PROPORCIÓN	SALUD	INFLAMABILIDAD	REACTIVIDAD

0	1	2	3	4
Minimal	Slight	Moderate	Serious	Severe
Mínimo	Mínimo	Moderar	Grave	Drástico

Multi-Surface Cleaner/Degreaser Ready To Use

DIRECTIONS

USE INFORMATION

Multi-Surface Cleaner/Degreaser cuts through tough dirty films and removes smears, fingerprints, bugs and other soils from glass and other hard surfaces. Works on most hard surfaces including sealed wood, marble and tile. Not for use on unsealed wood surfaces.

CLEANING

Always remove sand and grit with a water rinse when cleaning acrylic and Plexiglas®. Never spray into electrical circuits.

1. **SPRAY** a fine mist onto the entire surface to be cleaned.
2. **WIPE and POLISH** the surface until dry with a clean lint free cloth, paper towel or microfiber cloth.

FIRST AID:

If in eyes or on skin, immediately flush with plenty of water for at least 15 minutes. Get medical attention if irritation persists.

HANDLING AND STORAGE:

SUGGESTED STORAGE TEMPERATURE: Store inside at 40-90°F. **SPECIAL HANDLING AND STORAGE:** Handle in accordance with good industrial hygiene and safety practices. These practices include avoiding unnecessary exposure and removal of material from eyes, skin and clothing. Store in a cool and dry ventilated area. Protect from freezing. Thoroughly rinse empty containers. **KEEP OUT OF REACH OF CHILDREN.**

PERSONAL PROTECTION:

Respiratory Protection: Not needed under normal use of this product.

Ventilation: Use with adequate ventilation.

Other Protective Clothing or Equipment: Wear clothing as necessary to prevent skin contact.

TRANSPORTATION INFORMATION:

U.S. DOT - Proper Shipping Name: Not-Restricted

Marine Pollutant: No

MSDS RETRIEVAL
Read MSDS before using this product

800-848-4901

www.franklintechnology.com

OBTENCIÓN DE HDSM

Leer la HDSM antes de utilizar este producto

FOR CHEMICAL EMERGENCY,
SPILL, LEAK, FIRE, EXPOSURE OR ACCIDENT
CALL CHEMTREC DAY OR NIGHT

800-424-9300

PARA EMERGENCIAS QUÍMICA DERRAMES,
ESCAPES, FUEGO, EXPOSICIÓN O ACCIDENTE
LLAMAR DE DÍA O DE NOCHE A CHEMTREC

TECH HOTLINE
800-810-4829
LINEA DE TÉCNICA

CLEANING TECHNOLOGIES GROUP™

a division of CPAC

© FRANKLIN Cleaning Technology® 2007 • Great Bend, KS 67530

F0624TDS-0107