



F2130

Butcher Block Whitener

PRODUCT DESCRIPTION:

Butcher Block Whitener is formulated with a powerful combination of sodium hypochlorite, caustic soda and detergents, for use in meat, poultry and fish processing areas, delicatessens, restaurant kitchens and bakeries. Use **Butcher Block Whitener** to remove blood, fats, marrow and protein soils from butcher blocks, tables and other food processing equipment.

FEATURES:

Powerful Whitening:

Special formula removes tough stains from butcher blocks and other equipment.

"Clean" fragrance:

Leaves equipment with the sanitized fragrance of bleach, for added assurance of cleanliness.

PRODUCT SPECIFICATIONS:

pH (concentrate)	12.5 ± 0.5
Appearance	Clear Yellow Liquid
Fragrance	Chlorine
Freezing Point	About 32°F
Solubility in Water	Complete
Flash Point	None

INGREDIENTS:

Water	7732-18-5
Sodium hypochlorite	7681-52-9
Sodium hydroxide	1310-73-2

ECOLOGICAL INFORMATION

- Biodegradable Surfactants
- Contains no Phosphorus

DILUTIONS	HEALTH	FLAMMABILITY	REACTIVITY
CONCENTRATE CONCENTRAR	NFPA 3 HMIS	NFPA 0 HMIS	NFPA 1 HMIS
PROPORCIÓN	SALUD	INFLAMABILIDAD	REACTIVIDAD

0	1	2	3	4
Minimal	Slight	Moderate	Serious	Severe
Mínimo	Mínimo	Moderar	Grave	Drástico

Butcher Block Whitener

DIRECTIONS

USE INFORMATION

Remove all food and food packaging items before using this product. Scrape or brush away all heavy soil deposits on surface.

GENERAL SURFACE WHITENING



GENERAL SURFACE WHITENING

1. **RINSE** surface completely.
2. **APPLY** undiluted product onto surface to be whitened.
3. **SOAK** for 5 to 10 minutes.
4. **SCRUB** surface with brush.
5. **RINSE** surface completely with fresh potable water.

Note: If sanitation step is required, use a quality Franklin sanitizer after cleaning with **Butcher Block Whitener**.

FIRST AID:

If in eyes or on skin, immediately flush with plenty of water for at least 15 minutes while removing contaminated clothing and shoes. Get medical attention. Wash clothing before reuse. Thoroughly clean shoes before reuse. **If inhaled**, remove to fresh air. Get medical attention. **If swallowed**, do NOT induce vomiting. Get medical attention. NEVER GIVE ANYTHING BY MOUTH TO AN UNCONSCIOUS PERSON.

HANDLING AND STORAGE:

SUGGESTED STORAGE TEMPERATURE: Store inside at 40-90°F. **SPECIAL HANDLING AND STORAGE:** Handle in accordance with good industrial hygiene and safety practices. These practices include avoiding unnecessary exposure and removal of material from eyes, skin and clothing. Store in a cool and dry ventilated area. Protect from freezing. Thoroughly rinse empty containers. **KEEP OUT OF REACH OF CHILDREN.**

PERSONAL PROTECTION:

Respiratory Protection: Not needed under normal use of this product.

Ventilation: Use with adequate ventilation.

Eye Protection: Safety glasses are required.

Protective Gloves: Protective gloves are required.

Other Protective Clothing or Equipment: Wear clothing as necessary to prevent skin contact.



TRANSPORTATION INFORMATION:

U.S. DOT - Proper Shipping Name: Consumer Commodity, ORM-D

Marine Pollutant: No

MSDS RETRIEVAL
Read MSDS before using this product

800-551-0101

www.franklintechnology.com

OBTENCIÓN DE HDSM
Leer la HDSM antes de utilizar este producto

**FOR CHEMICAL EMERGENCY,
SPILL, LEAK, FIRE, EXPOSURE OR ACCIDENT
CALL CHEMTREC DAY OR NIGHT
800-424-9300**

**PARA EMERGENCIAS QUÍMICA DERRAMES,
ESCAPES, FUEGO, EXPOSICIÓN O ACCIDENTE
LLAMAR DE DÍA O DE NOCHE A CHEMTREC**

**TECH HOTLINE
800-810-4829
LINEA DE TÉCNICA**

CLEANING TECHNOLOGIES GROUP™

a division of CPAC

© FRANKLIN Cleaning Technology™ 2001 • Great Bend, KS 67530

F2130TDS-1100