

**BIG BOSS**<sup>®</sup>  
**CLEANER/DEGREASER**

**CONCENTRATED FORMULA**

**GENERAL INFORMATION**

BIG BOSS<sup>®</sup> CLEANER/DEGREASER is a non-flammable, water-soluble degreaser that exhibits highly efficient soil removal and degreasing properties in a wide variety of cleaning operations. It is effective for use on concrete floors, machinery, tools, greasy machine parts, enamel-coated metal wall sheeting, flumes, ventilators, stoves, ovens, wood and synthetic duckboards. This unusually versatile product can also be employed to strip acrylic water emulsion floor sealers. Its active ingredients include heavy-duty detergents, cleaning and degreasing agents, a sequestrant, a hydrotrope and a water-soluble solvent. Contains no phosphorus.

BIG BOSS<sup>®</sup> CLEANER/DEGREASER leaves no residual film, thus eliminating the need for excessive or repeated water rinsings. It features variable rate dilution ability for many hard-to-handle cleaning and degreasing problems, as well as problem surfaces.

**NOTE:** While this product can be employed to strip water emulsion sealers from resilient flooring, it should not be used for routine maintenance on resilient floorings such as asphalt, linoleum, vinyl or vinyl asbestos, rubber, etc., as it may affect additional coats of floor finish.

**APPLICATION**

BIG BOSS<sup>®</sup> CLEANER/DEGREASER can be applied by mop, sponge, sprayer or scrubber. Manual scrubbing or machine scrubbing can be employed depending upon the nature of the cleaning operation.

**HOW TO USE**

The following use directions and dilution rates have been designed to generally fit the broadest range of applications. It should be noted that slight modifications in procedure may be necessary because of mechanical differences in equipment, different maintenance schedules, etc.

**Greasy Concrete Floors:** 1 to 10 dilution (13 oz. per gallon of water); mop on and let stand for five minutes. Machine scrub or hand scrub with wire deck brush and flush with clear water.

**Machinery, Tools or Greasy Machine Parts:** Soak in a 1 to 10 dilution (13 oz. per gallon of water) using hot water.

**Stoves and Ovens:** 1 to 10 dilution (13 oz. per gallon of water); spray or sponge on.

**Enamel-Coated Metal Wall Sheeting:** 1 to 20 dilution (6½ oz. per gallon of water).

**Ventilators and Flumes:** 1 to 10 dilution (13 oz. per gallon of water).

**Seal Stripping:** For stripping acrylic undercoaters and sealers, use a dilution of 1 to 10 (13 oz. per gallon of water). Mop on the floor, let stand for three to five minutes, and machine scrub using a scrubbing or stripping pad. Rinse thoroughly with clear water.

**General Cleaning:** 1 to 80 dilution (1½ oz. per gallon of water).

# FRANKLIN BIG BOSS®

## CLEANER/DEGREASER

### DETAILED REQUIREMENTS

Appearance:	Clear, purple liquid
Odor:	Sassafras
Viscosity:	Water-thin
pH @ 77° F:	
Concentrate:	12.7 - 13.2
1:10 dilution:	12.1 - 12.5
1:20 dilution:	11.5 - 11.9
1:80 dilution:	10.8 - 11.2
Residual Film:	None: free-rinsing with cold water or steam.
Emulsification Ability:	Superior
Soil Suspension Ability:	Superior
Soil Penetration:	Superior
Dilution with Water:	Complete in all proportions
Compatability:	Satisfactory for use on most metal surfaces normally expected to be degreased.

**IMPORTANT:** Use only as directed. Do not mix with anything unless recommended since harmful conditions and poor performance could result. Do not pour unused product back into original container.

All floors are slippery when wet. To prevent falls, exercise care when working and block off traffic with "Danger" signs until the polish or floor is completely dry.

Low-speed machines and wet stripping are recommended by the EPA when stripping vinyl asbestos flooring.

Contains 2-Butoxy ethanol which may cause damage to the kidneys, liver, and blood-forming system based on laboratory animal data. May be harmful if absorbed through skin or swallowed in large quantities.

**DANGER!** Do not get in eyes, on skin, or on clothing. Avoid breathing vapors. Keep container closed. Use with adequate ventilation. Wash thoroughly after handling. Do not taste or swallow.

**FIRST AID: If in eyes or on skin:** Immediately flush with plenty of water for at least 15 minutes while removing contaminated clothing and shoes. Get medical attention. Wash clothing before reuse. **If inhaled:** Remove to fresh air. If not breathing, give artificial respiration. If breathing is difficult, give oxygen. Get medical attention. **If swallowed:** Do NOT induce vomiting. Give water to drink. Get medical attention. NEVER GIVE ANYTHING BY MOUTH TO AN UNCONSCIOUS PERSON.

**NOTE:** Not recommended for daily maintenance of resilient floors such as asphalt, linoleum, vinyl or vinyl asbestos, rubber, etc.

For Professional Sanitary Maintenance Use Only.

**¡¡IMPORTANTE AVISO!** Si Ud. no sabe como se usa este producto, pida ayuda de su capataz o supervisor.

Before using, read Material Safety Data Sheet (MSDS) for this product.

**NOT FOR SALE FOR RESIDENTIAL USE — NON-PHOTOCHEMICALLY REACTIVE (MORE THAN 4%)**

**RIGHT TO KNOW INFORMATION FOR NJ & PA**

Water .....	7732185
2-Butoxy ethanol .....	111762
Sodium metasilicate .....	6834920
Nonyl phenoxy poly(ethyleneoxy)ethanol .....	9016459
Disodium dicarboxylate .....	67785313
Purex Industrial (614) 387-6200	

**FOR CHEMICAL EMERGENCY**  
**Spill, Leak, Fire, Exposure or Accident**  
**CALL CHEMTREC DAY OR NIGHT**  
**800-424-9300**

F2660 10/95

**KEEP OUT OF REACH OF CHILDREN**

FRANKLIN MAINTENANCE PRODUCTS ARE DISTRIBUTED BY:

**Franklin**  
 MAINTENANCE PRODUCTS